

Quick Installation Guide

NComputing L-series access devices with vSpace



Your NComputing access device works with the following operating systems:

- Windows
- Linux

Operating system support may change without prior notice. Please see our website for the latest operating system support information.

© 2008 NComputing. All rights reserved. Specifications subject to change without notice. NComputing® is the property of NComputing and may be registered in USA and other countries. Microsoft and Windows are registered trademarks of Microsoft Corporation. Other trademarks and trade names are the property of their respective owners.

Rev.C
Part No. 162-0034

Step 1 Connect the access device

L230 / L130

L230

L130


*L230 only.

1 USB Flash memory port*	4 Video port	7 Power on/off switch
2 LAN port (RJ45)	5 Speaker output	8 Microphone input
3 Mouse/keyboard port	6 DC power input	

Peripherals are not included.

Note Configure the access device first, and then install the vSpace software.

Step 2 Hardware Installation



Step 3 Configure the access device

Click the "Options" button

Click the "Setup" button

Get Dynamic IP Address

- Select the "Network" tab
- Select the "Dynamic IP address" radio button
- Click the "Save" button

Use Static IP Address

- Select the "Network" tab
- Select the "Use Static IP Address" radio button
- Enter the static IP address for the access device
- Click the "Save" button

- Select the "Options" tab
- In the "Server Connection List," select "Autodetection" and click on the "Edit" button.

- Set the desired video resolution in the "Desktop Size" section.
- Click the "OK" button.
- Click the "Save" button in the "Setup" window

Step 4 vSpace Software Installation

Note : Connect the access devices and the host PC to the network when installing and registering the software. This assures the software will retrieve and register the serial numbers from each access device via the Ethernet connection.

- Run the installation program instructions.
- Follow the on-screen instructions.
- Add new users as necessary.

- After the reboot is complete, register the software and the access devices by launching "vSpace Registration" and following the instructions.
- If you are adding access devices to an existing installation, you must register each access device.

Step 5 Use the access device

Select the host PC, or server, and click the 'Connect' button.

Step 6 How to use the VESA mounting bracket

